


Sigma CP - 3 Wire Connection Diagram



EOL = END OF LINE DEVICE

CP = CALL POINT

S = SOUNDER

Sigma CP PCB